

START A NEW CHAPTER.

Appreciated: Deluxe cab.

- Efficient and user-friendly operating concept
- Optimal all-round visibility with blind spot check


Even more efficient: RS machine variant.



- Compaction, loading and transporting with one machine

Perfectly set up: Hydrostatic travel system.

- Power limit control for optimal performance
- Automatic and infinitely variable for the best efficiency





High air intake position: Minimal cleaning requirements.

- Air intake in area with the lowest dust load
- Speed-controlled reversible cooling fan for constant cooling capacity at highest efficiency (cooling on demand)

Greater efficiency: Engine technology.

- ECOMODE and ECOSTOP reduce fuel consumption and wear

Made easy: Service and maintenance.

- Access to all components: one-piece engine cover with electro-hydraulic opening
- Daily inspection performed on one side of the machine

Functional: Platforms and steps.

- Open, sturdy design stays clean and safe
- Safe service and maintenance

Effective by design: The compaction concept.

- Wheels with a polygon profile and teeth for optimal crushing and kneading
- Scrapers ensure clean tools and constant compaction performance
- Cable cutters prevent wires and ropes from becoming entangled

Reliably on the ground: Oscillating articulated joint.

- Best adaptation to the landfill surface
- Excellent traction and compaction

Head Office:

BOMAG
Hellerwald
56154 Boppard
GERMANY
Tel. +49 6742 100-0
Fax +49 6742 3090
info@bomag.com

**BOMAG Maschinen-
handels-gesellschaft m.b.H.**
Klausenweg 654
2534 Alland
AUSTRIA
Tel. +43 2258 20202
Fax +43 2258 20202-20
austria@bomag.com

BOMAG MARINI EQUIPAMENTOS LTDA.
Avenida Clemente Cifali, 530
Distrito Industrial Ritter
Cachoeirinha – RS
BRAZIL
ZIP code 94935-225
Tel. +55 51 2125-6642
Fax +55 51 3470-6220
brasil@bomag.com

BOMAG (CANADA), INC.
2233 Argentia Road, East Tower
Suites 302
Mississauga, ON, Canada
L5N 2X7
Tel. +1 800 782 6624
Fax +1 905 361 9962
canada@bomag.com

BOMAG (CHINA)
Compaction Machinery Co. Ltd.
No. 2808 West Huancheng Road
Shanghai Comprehensive
Industrial Zone (Fengxian)
Shanghai 201401
CHINA
Tel. +86 21 33655566
Fax +86 21 33655508
china@bomag.com

BOMAG India Pvt Ltd
Unit No. 614, B Wing, 6th Floor
Kanakia Wall Street
Chakala Andheri Kurla Road Andheri East
Mumbai 400 093 Maharashtra
INDIA
Tel.: +91 8657492418
india@bomag.com

BOMAG France S.A.S.
2, Avenue du Général de Gaulle
91170 Viry-Châtillon
FRANCE
Tel. +33 1 69578600
Fax +33 1 69962660
france@bomag.com

BOMAG (GREAT BRITAIN), LTD.
Sheldon Way
Larkfield, Aylesford
Kent ME20 6SE
GREAT BRITAIN
Tel. +44 1622 716611
Fax +44 1622 710233
gb@bomag.com

BOMAG Italia Srl.
Via Roma 50
48011 Alfonsine
ITALY
Tel. +39 0544 864235
Fax +39 0544 864367
italy@bomag.com

FAYAT BOMAG Polska Sp. z o.o.
Ul. Szyszkowa 52
02-285 Warszawa
POLAND
Tel. +48 22 482 04 00
Fax +48 22 482 04 01
poland@bomag.com

FAYAT BOMAG RUS OOO
141400, RF, Moscow region
Khimki, Klayazma block, h. 1-g
RUSSIA
Tel. +7 (495) 287 92 90
Fax +7 (495) 287 92 91
russia@bomag.com

BOMAG GmbH
300 Beach Road
The Concourse, #18-06
Singapore 199555
SINGAPORE
Tel. +65 6 294 1277
Fax +65 6 294 1377
singapore@bomag.com

BOMAG Americas, Inc.
125 Blue Granite Parkway
Ridgeway SC 29130
U.S.A.
Tel. +1 803 3370700
Fax +1 803 3370800
usa@bomag.com

